

Berker waterproof ranges

Berker ISO Panzer (IP44)	2
<hr/>	
Berker ISO Panzer (IP66)	3
<hr/>	
Berker Diecast IP44	4
<hr/>	

**socket outlets SCHUKO with hinged cover**

Description	P.U.	Cat ref.
SOCKET OUTLET ISO-PANZER	1	4280
SOCKET OUTLET 2GANG ISO-P	1	4370
SOCKET OUTLET 2GANG ISO-P	1	4322
SOCKET OUTLET 3GANG ISO-P	1	4323

4280

**Rocker switch**

Description	P.U.	Cat ref.
CHANGE-OVER SWITCH ISO-P.	1	3446

3446

**Rocker push button**

Description	P.U.	Cat ref.
MOM.CONT.SWITCH ISO-PANZ.	1	504101



504101

**Switch for lock cylinder**

Description	P.U.	Cat ref.
KEY SWITCH/CHANGE-OVER 2P	1	4386

4386

**Combination switch/socket outlet SCHUKO**

Description	P.U.	Cat ref.
COMBIN.SWITCH/SOCKET ISO	1	4246
SCHUKO-SOCKET/KEY SW. ISO	1	4432

4246



Socket outlet / plug SCHUKO

Description	P.U.	Cat ref.
SOCKET OUTLET/HINGED COV.	1	4283
PLUG F.SPLASH-PROOF SOCK.	1	4631

4283



Rotary switch

Description	P.U.	Cat ref.
ROTARY CHANGE-OVER SWITCH	1	3046
SERIES ROTARY SW. ISO-P.	1	3045
ROTARY SW.CHANGE-OVER ILL	1	3146
ROTARY SWITCH 2P.LIGHTED	1	3142

3046



Rotary switch for blinds / shutters

Description	P.U.	Cat ref.
MOM.CONT.SW.F.SHUTTERSISO	1	4342

4342

**Lock cylinder**

Description	P.U.	Cat ref.
P-H CYLIND.ASSORT.LOCKING	1	1818

1818