

Switch disconnectors

Switch disconnectors are used as general switches in electrical low voltage distribution boards and for isolation of loads during the interventions of maintenance.



Modular isolators	2
NH switch disconnectors	3
Switch disconnectors	4



SBN216

Double pole

Description	P.U.	Cat ref.
2P 16A Switch	1	SBN216
2P 25A Switch	1	SBN225
2P 32A Switch	1	SBN232
2P 40A Switch	1	SBN240
2P 63A Switch	1	SBN263
2P 80A Switch	1	SBN280
2P 100A Switch	1	SBN290



SBN316

Three pole

Description	P.U.	Cat ref.
3P 16A Switch	1	SBN316
3P 25A Switch	1	SBN325
3P 32A Switch	1	SBN332
3P 63A Switch	1	SBN363
3P 80A Switch	1	SBN380
3P 100A Switch	1	SBN390
3P 40A Switch	1	SBN340



SBN416

Four pole

Description	P.U.	Cat ref.
4P 16A Switch	1	SBN416
4P 25A Switch	1	SBN425
4P 32A Switch	1	SBN432
4P 40A Switch	1	SBN440
4P 63A Switch	1	SBN463
4P 80A Switch	1	SBN480
4P 100A Switch	1	SBN490



LT150

Horizontal type

Description	P.U.	Cat ref.
Disconnector size 000 3x100A	1	LT0059
Fuse switch, NH00, 3x160A	1	LT059
Fus.-swi.-disconn. LT size 1 mon.pl. M10	1	LT150
Fus.-swi.-disconn. LT size 2 mon.pl. M10	1	LT250
Fus.-swi.-disconn. LT size 3 mon.pl. M10	1	LT350
Fus.-swi.-disconn. LT size 00 60mm BC	1	LT056
Fus.-swi.-disconn. LT size 1 60mm M10	1	LT153
Fus.-swi.-disconn. LT size 2 60mm M10	1	LT253
Fus.-swi.-disconn. LT size 3 60mm M10	1	LT353



LVS0060SP

Vertical type

Description	P.U.	Cat ref.
Fuse switch vert. size 00/60 3p M8	1	LVS0060SP
Fuse switch vert. Size 00/100 3p M8	1	LVS00100SP
Fuse switch vert. size 00 185 3P M8	1	LVSG00SP
Fuse switch vert. Size 2 long TC	1	LVSG2CPZ
Fuse switch vert. size 3 long TC	1	LVSG3CPZ
Disconnector vertical size3 1000A 3p M12	1	LVTG1000CP
Fuse switch vert. size 00 185 1P M8	1	LVSG00SE
Fuse switch vert. size 1 185mm 1p M12	1	LVSG1CE
Fuse switch vert. size 2 1p M12	1	LVSG2CE
Fuse switch vert. size 3 1p M12	1	LVSG3CE
Fuse switch vert. size 1 3p M12	1	LVSG1CPX



SBN340

Three pole

Description	P.U.	Cat ref.
3P 40A Switch	1	SBN340