


Berker - Light controls


switching	2
dimming	5
Light signals	6



3031

Rocker switch insert


Description	P.U.	Cat ref.
rocker switc on/off Module insert	10	3031
ON/OFF SWITCH 2POLE	10	3032
Change-over switch 10AX 250V~	10	3036
rocker switc intermediate Module insert	10	3037
SWITCH FOR INSERTS	10	303212



3035

2-Rockers switch insert


Description	P.U.	Cat ref.
Rockers switch Module inserts	10	3035
Rockers switch Module inserts	10	303808



633023

3-Rockers switch insert


Description	P.U.	Cat ref.
Rockers switch Module inserts	10	633023



5031

Rocker push button insert


Description	P.U.	Cat ref.
Rocker push-button NO contact Module ins	10	5031
Rocker push-button Module inserts	10	5036
MOMENTARY CONTACT SWITCH	10	503203



5035

2-Rockers push button insert


Description	P.U.	Cat ref.
Rockers push-button Module inserts	10	5035
Group rockers push-butto 4 NO, common i	10	503404
Rockers push-button Module inserts	10	503501
Rockers push-button for blind 1pole Mod	10	503520
Rockers push-button Module inserts	10	503808



387500

Rotary switch

Description	P.U.	Cat ref.
Rotary Switch Series 1930 Glass	1	387500
Rotary switch change-over serie1930/Glas	1	387600
Rotary Switch Intermediate 1930 Glass	1	387700



383800

Rotary push button

Description	P.U.	Cat ref.
Group spring return push-button 1930	1	383800
Rotary Push Button Change-over NC or NO	1	384600



3966

Pullcord switch


Description	P.U.	Cat ref.
PULLCORD SWITCH	10	3966
PULLC.PUSHB.SW.M2 PW	10	395619



1818

Key switch


Description	P.U.	Cat ref.
P-H CYLIND.ASSORT.LOCKING	1	1818



505102

Push button insert for HotelCard

Description	P.U.	Cat ref.
Switch push button for hotelcard	10	505102
MODUL-EINSÄTZE WIP-TA W F HOTELC-SCH	10	505601



Timer relais switch

Description	P.U.	Cat ref.
ZEIT-RELAIS-SCHALTEINSATZ HAUSELEKTRONIK	1	294810

294810



Glow and neon lamp units

Description	P.U.	Cat ref.
Neonlamp unit w/N-terminal, 230V/1m -grey	10	1675
GLOW LAMP UNIT 6 V	10	1676
GLOW LAMP UNIT 6 V	10	167602

1675



2873

Rotary dimmer

Description	P.U.	Cat ref.
Rotary dimmer (R, L, LED), Light control	1	2873
TRONIC-DREHDIMMER MIT SOFTRASTUNG HAUS..	1	2874
Rotary dimmer with soft-lock	1	2875
1,000W Rotary dimmer with soft-lock	1	2885
Rotary Dimmer - Inc. & hal. lamp 60-400W	10	281901
Rotary dimmer House electronics	1	283010
ROTARY DIMMER	1	286010
Universal rotary dimmer w/soft-lock	1	286110
Universal rotary dimmer extension unit	1	286210
Rotary dimmer LV House electronics	1	286610
TRONIC-DREHDIMMER HAUSELEKTRONIK MIT D..	1	286710



2897

DALI rotary potentiometer

Description	P.U.	Cat ref.
Rotary Potentiometer DALI	1	2897



289110

Rotary potentiometer 1-10 V


Description	P.U.	Cat ref.
Electronic rotary potentiometer 1-10 V	1	289110
Push Button Rotary Potentiometer 1-10V	1	289610



1659901

Universal power booster (RMD)

Description	P.U.	Cat ref.
UNI-LZ REG P	1	1659901



5101

Push button for light signal

Description	P.U.	Cat ref.
P/button and pilot lamp E10 inserts	10	5101
FLUSH MOM.CONT.SW./P.LAMP	10	510110



2949

Info Light signal


Description	P.U.	Cat ref.
INSERT PILOT LAMP 230V	1	2949



1601

Incandescent, neon and LED lamps

Description	P.U.	Cat ref.
NEON LAMP BULB E10 220V	100	1601
LED Lamp E10 White	10	1678
LED-LEUCHTMITTEL E10 ROT	10	167801
LED-LEUCHTMITTEL E10 GELB	10	167802
LED-LEUCHTMITTEL E10 GRÜN	10	167803
LED-LEUCHTMITTEL E10 BLAU	10	167804



1279

Accessories

Description	P.U.	Cat ref.
BUTTON F. 5101, RED	10	1279
SCREEN TPR RED	10	1289