



Berker - Blind/shutter controls



303520

Switch insert (1 pole)


Description	P.U.	Cat ref.
Rockers switch for shutters inserts	10	303520



3841

Rotary switch (1 pole)

Description	P.U.	Cat ref.
Rotary switch for shutters inserts	10	3841



3842

Rotary switch (2 pole)

Description	P.U.	Cat ref.
Rotary switch for shutters inserts	10	3842



2930

Cut off relais

Description	P.U.	Cat ref.
ROLLOTEC TRENNRELAIS HAUSELEKTRONIK UP	1	2930
ROLLOTEC TRENNRELAIS REG HAUSELEKTRONI..	1	2931